

EQUIPMENT SERVICE *ON SITE*

EquiServ™



*Providing Factory Service For
Automotive Service Equipment*

**Model: EECS501A
EECS502A**

Page: 1 of 1

Installation Instructions

**INSTALLATION MUST BE PERFORMED
BY
QUALIFIED EQUISERV PERSONNEL ONLY**

INSTALLATION OVERVIEW: _____

The Installation Procedures listed are for the JBC Proline 450 units. The unit is shipped as a fully assembled unit, with the exception of the items listed in the Parts & Accessories

PARTS & ACCESSORIES : _____

PART NUMBER	DESCRIPTION	QTY
EAA0183L02A	Current Probe	1
2-4242	Volt / Ohm leads	1
TEECS502A	Installation Instructions	1

INSTALLATION INSTRUCTIONS: _____

1. Open top of box. Split one corner and unwrap box off cart.
2. Remove the plastic bag from unit.
3. Cut the strap and remove the box on shelf.
4. Remove the Proline 450 from the box.
5. Slide the front of the Proline 450 into the two key slots in front on top of the assembled cart.
6. Slowly lower the rear of the Proline 450 until it locks into clip attached to top shelf of cart.
7. Connect current probe (EAA0183L02A) to front panel connector.
8. Place volt/ohm leads (2-4242) on cart shelf.

INSTALLATION COMPLETE