



Model: VIP 1R-5 KIT, VIP 1R-10 KIT
For MCS-2500, MCS-4000,
MGA-9000, and ETB

Page: 1 of 3

Installation Instructions

**INSTALLATION MUST BE PERFORMED
BY
QUALIFIED SNAP-ON/SUN PERSONNEL ONLY**

INSTALLATION OVERVIEW:

This kit is for the installation of the VIP 1R-5 AND VIP-1R-10 for the MCS-2500, MCS-4000, MGA-9000, and the ETB. The kit includes all the parts necessary to correctly install VIP-1R.

PREREQUISITE:

MCS-2500 must have a PC Interface kit #1091-0313-01 and Power Distribution kit #1091-0316-01.
MCS-4000 must have a PC Interface kit #1091-0235-01.
MGA-9000 must have a PC interface kit #1091-0235-02.
ETB must have a PC Interface kit #AA-800.

PARTS & ACCESSORIES LIST FOR:

| PART NUMBER | DESCRIPTION | -5 QTY | -10 QTY |
|--------------|---|--------|---------|
| 0552-0043 | GM and FORD Coil Adapter | 1 | 1 |
| 0552-0044 | GM External Coil Adapter | 1 | 1 |
| 0552-0045 | GM Micro Pack Adapter | 1 | 1 |
| 1747-0101 | Pattern, Pickup, Chrome | 1 | 1 |
| 1747-0102 | HEI Pickup | 1 | 1 |
| 6004-0462 | Volt/Ohm Test Lead, Pink, 10ft | | 1 |
| 6004-0462-01 | Volt/Ohm Test lead, Pink, 5ft | 1 | |
| 6004-0544-01 | Pattern, Dual, Assembly, Blue, 5ft | 1 | |
| 6004-0544-02 | Pattern, Dual, Assembly, Black, 10ft | | 1 |
| 6004-0763-01 | Pattern Lead Conventional, Blue, 5ft | 1 | |
| 6004-0763-02 | Pattern Lead Conventional, Blue, 10ft | | 1 |
| 6004-0768-01 | Cable Assembly, Pod | 1 | 1 |
| 6005-0182-01 | Universal Test Lead Assembly, 5ft | 1 | |
| 6005-0182-02 | Universal Test Lead Assembly, 10ft | | 1 |
| 7009-2376-02 | VIP-1 Assembly | 1 | 1 |
| 7009-2325-01 | Trigger Pickup and Lead Assembly, Red, 5ft | 1 | |
| 7009-2325-02 | Trigger Pickup and Lead Assembly, red, 10ft | | 1 |
| 0692-2315-01 | Installation Instructions | 1 | 1 |
| 0692-1834-01 | SEL 1403c, Questionnaire | 1 | 1 |
| 0692-1034-01 | Label, Key Board | 1 | 1 |
| 0692-2317-01 | Operator's Manual | 1 | 1 |

REQUIRED TOOLS: _____

- ② COMPLETE ISSUED TOOL KIT
- ② ANTI-STATIC KIT

INSTALLATION INSTRUCTIONS: _____



WARNING!

**USE STANDARD ANTI-STATIC PROCEDURES
WHILE PERFORMING THIS PROCEDURE**

1. After performing the initial checkout and any necessary repairs, switch off the tester and disconnect it from the power source.
2. Connect the POD Cable Assembly (6004-0768-01) from the VIP-1R assembly connector to the VIP-1R connector on the back of the tester.
3. **NOTE:** *Make sure both the beige seals are installed. If one is missing order PN 4162-0947.*
4. Connect the Trigger Pickup and Lead Assembly (7009-2325-**) to the Trigger Pickup Lead connector on the VIP-1R assembly.
5. Connect the Universal Test Lead Assembly (6005-0182-**) to the Universal Test Lead Connector on the VIP-1R Assembly.
6. Connect the Volt/Ohm Test Lead Assembly (6004- 0462-**) to the Volt/Ohm Connector on the VIP-1R Assembly.
7. Connect the Pattern Pickup (1747-0101) to the Conventional Pattern Lead (6004-0763-**).
8. Connect the Pattern Pickup Assembly from the previous step to the Pattern Pickup Connector on the VIP-1R.
9. Clean the keyboard surface to remove dirt and dust. Peel the backing off the Keyboard Label (0692-1034-01) and place the label around the function keys as shown in Figure 1.




Figure 1 Keyboard Label

10. Place Adapter (0552-0043), Adapter (0552-0044), Adapter (0552-0045), HEI Pickup (1747-0102) and Dual Pattern Lead Assembly (6004-0544-**) in the Storage Drawer.

** The dash number of the leads depends on the dash number of the kit being installed. See the parts list on page one for dash numbers.

* **INSTALLATION COMPLETE** *

CHECKOUT PROCEDURE: _____

1. Connect tester to AC power and turn on.
2. Select **1. VIP Engine Analyzer**.
3. Select **Continue**.
4. Select **1. ID**, then **3. Vehicle Code**.
5. Type 115, then select **Continue**.
6. Select **3. Pin Point**, then **1. Engine Data**.
7. Connect the VIP-1R to an IS-100A and set it to 8 Cylinders, Delta KV on, and Ignition on.
8. Verify RPM, Dwell, KV, and Battery volts for proper operation.

* **CHECKOUT COMPLETE** *
