
Appendix C – Parts / TRANSTECH® II-A (EETF102A / MTT1100)

External Parts for the TRANSTECH® II –A / Transmission Service System Please refer to the part numbers below when ordering parts for this unit.


<u>Part #</u>	<u>Description</u>
010-0027	Wheel
010-0026	Wheel Hub cap
010-6000	Swivel caster
010-6001	Swivel caster with brake lock
010-5004	Hose bracket
010-5200	Overlay, TRANSTECH II (Version A)
010-5602	Adapter Box
010-6060	Reservoir cap
011-0031	Handle, steel
020-5331	Printed Circuit Board (Version A)
020-8043	Harness, External Power
020-1010	Harness, Internal Power
020-1600	Internal Light / Incandescent (No longer available)
020-1601*	Internal Light / Fluorescent Lamp (Alone)
200-8639	Fluorescent Lamp, Retro-Fit Assembly
020-5332	Fuse, 10 Amp Fast Blow, GMA Type
040-0612	Screw, Allen Head, ¼-20 x ½ (Handle)
040-0613	Screw, Phillips, stainless steel 6-32 (Rear panel)
040-0623	Screw, Allen Head, 8-32 x 5/8 (Control Panel)
040-1200	Screw 5/8 php x #6 (for adapter box)
040-2000	Flat washer #6 (for adapter box)
040-2200	Threaded Standoff (for adapter box)
050-1000	Screen filter inline ½ MPT. Pp.
050-3001	Check valve, (disposal hose)
060-5810	Cap plug (handle)
080-0230	Female Quick Disconnect Couplers, 1/4", Ni
200-8611	Output/Return hose assembly
200-8665	Output/Return hose assembly / Clear / braided type
200-8612	Disposal hose assembly
200-8220	Operators Manual
200-8303	Quick Reference Card TRANSTECH II-A
200-3100	Adapter Kit (standard)
200-3101	Adapter Kit (deluxe)
050-2300	Manifold Block (alone)
	 Designates late production units

200-8653 **NEW FLUID TANK** ASSEMBLY. (COMPLETE) NOTE: All attached fittings are the same as Waste Fluid Tank components. 010-5802 -New fluid tank 26- Qt. Crosslink, Plastic. 200-8654 WASTE FLUID TANK 030-4602 ASSEMBLY. (COMPLETE) Elbow fitting- male 3/8 x 1/4 NPT. 200-0043 Connector-male 3/8 x 1/4 Drilled through, 3/8" bore. 010-5803 Waste fluid tank 26- Qt. Crosslink, Plastic. 030-4002 Connector-male 1/2 x 3/4 Drilled through, 1/2" bore. 050-2700 Level Switch 1/2" mount.


200-8657 FLUID PICK-UP TUBE ASSEMBLY





200-8658 PRESSURE TRANSDUCER TUBE ASSEMBLY




200-8643 CHECK VALVE ASSEMBLY









(Early Production Units)

Incandescent Lamp Assembly / N.L.A. 020-1600 (Mounting bracket not sold separately)



NOTE: NLA = No longer Available

(Late '99 & 2000 Production Units)

Fluorescent Lamp assembly 020-1601/ Lamp Alone 200-8639 / Retro-Fit Lamp Assembly




NOTE: If any components are equipped with a "Press-on" fitting, follow the next steps.

- 1. Press and hold hose to be removed firmly into the fitting.
- 1. Press the Compression ring into the body.
- 1. With compression ring pressed, pull the hose out of the fitting.

When installing; Hose needs to be inserted into the fitting approximately 3/4 in., (0.75"), to ensure proper seal onto the hose.

PUSH INSERT FIRMLY INTO BODY, DEPRESS COMPRESSION RING AGAINST BODY AND PULL HOSE.



ORDERING PARTS

Parts for the unit may be ordered by calling Customer Service, have your model and serial numbers available:

in the U.S. International:

(714) 558-4822 CALL YOUR LOCAL

(800) 841-8810 DISTRIBUTOR